RidersShare

PRE/POST RENTAL INSPECTION FORM

Please use this form to note all pre-existing damage on the motorcycle before proceeding with the rental. After the rental, please take note of any damage that was not there before the rental. Please remember that <u>if the renter is not in</u> <u>condition to ride the motorcycle (for example, intoxicated), the motorcycle owner may cancel the rental transaction</u> <u>with no refund to the renter.</u> RidersShare's contact information is <u>(657)</u> 200-5470 and support@riders-share.com

| PAINT | | | | | |
|----------------|--------------|---|--------------|--|--|
| Item | Check | Look for | Notes | | |
| Gas Tank | Condition | Scratches, dents, bent, caved, broken, loose, cracked, scraped, rubbed, nicked, faded, etc. | | | |
| Fenders | Condition | | Front - Rear | | |
| Fairings | Condition | | | | |
| Other | Condition | | | | |
| TIRES & WHEELS | | | | | |
| Item | Check | Look for | Notes | | |
| Tires | Condition | Tread depth, wear, weathering, evenly seated, bulges, imbedded objects. | Front - Rear | | |
| | Air Pressure | Check when cold, adjust to load/speed. | Front - Rear | | |
| Wheels | Spokes | Bent, broken, missing, tension, check at top of wheel: "ring" == ОК, "thud" == loose spoke. | Front - Rear | | |
| | Cast | Cracks, dents. | Front - Rear | | |
| | Rims | Out of round/true == 5mm. Spin wheel, index against a stationary pointer. | Front - Rear | | |
| | Bearings | Grab top and bottom of tire and flex: No freeplay (click) between hub and axle, no growl when spinning | Front - Rear | | |
| | Seals | Cracked, cut or torn, excessive grease on outside, reddish-brown outside. | Front - Rear | | |

| CONTROLS | | | | | |
|------------|-----------|--|--------------|--|--|
| Item | Check | Look for | Notes | | |
| Levers | Condition | Broken, bent, cracked, mounts tight, ball ends on handlebar lever. | Front - Rear | | |
| | Pivots | Lubricated. | | | |
| Cables | Condition | Fraying, kinks, lubrication; ends and length | | | |
| | Routing | No interference or pulling at steering head, suspension; no sharp angles, wire looms in place. | | | |
| Hoses | Condition | Cuts, cracks, leaks, bulges, chafing, deterioration. | | | |
| | Routing | No interference or pulling at steering head, suspension, no sharp angles, wire looms in place. | | | |
| Throttle | Operation | Moves freely, snaps closed, no revving. | | | |
| | | LIGHTS | | | |
| Item | Check | Look for | Check off | | |
| Battery | Condition | Terminals clean and tight, electrolyte level, held down securely. | | | |
| | Vent Tube | Not kinked, routed properly, not plugged. | | | |
| Lenses | Condition | Cracked, broken, securely mounted, excessive condensation. | | | |
| Reflectors | Condition | Cracked, broken, securely mounted. | | | |
| Wiring | Condition | Fraying, chafing, insulation. | | | |
| | Routing | Pinched, no interference or pulling at steering head or suspension, wire looms and ties in place, connectors tight, clean. | | | |
| Headlamp | Condition | Cracks, reflector, mounting and adjustment system. | | | |
| | Aim | Height and right/left. | | | |

| OIL | | | | | |
|------------|-------------------------------|---|-------|--|--|
| Item | Check | Look for | Notes | | |
| Levels | Engine Oil | Check warm on centerstand, dipstick, sightglass. | | | |
| | Hypoid Gear Oil | Transmission, rear drive, shaft. | | | |
| | Hydraulic Fluid | Brakes, clutch, reservior or sight glass. | | | |
| | Coolant | Reservoir and/or coolant recovery tank — cool only. | | | |
| | Fuel | Tank or guage. | | | |
| Leaks | Engine Oil | Gaskets, housings, seals. | | | |
| | Hypoid Gear | Gaskets, seals, breathers. | | | |
| | Hydraulic Fluid | Hoses, master cylinders, calipers. | | | |
| | Coolant | Radiator, hoses, tanks, fittings, pipes. | | | |
| | Fuel | Lines, fuel taps, carbs. | | | |
| | | CHASSIS | | | |
| Item | Check | Look for | Notes | | |
| Frame | Condition | Cracks at gussets, accessory mounts, look for paint lifting. | | | |
| | Steering-Head Bearings | No Detent or tight spots through full travel, raise front wheel, check for play by pushing/pulling forks. | | | |
| | Swingarm Bushings/Bearings | Raise rear wheel, check for play by pushing/pulling swingarm. | | | |
| Suspension | Forks | Smooth travel, equal air pressure/damping and anti- dive settings. | | | |
| | Shock(s) | Smooth travel, equal preload, air-pressure and damping settings, linkage moves freely and is lubricated. | | | |

| CHASSIS | | | | | |
|-------------|-------------|---|-------|--|--|
| ltem | Check | Look for | Notes | | |
| Chain/belt | Tension | Check at tightest point. | | | |
| | Lubrication | Side plates when hot. Note: do not lubricate belts! | | | |
| | Sprockets | Teeth not hooked, securely mounted. | | | |
| Fastners | Threaded | Tight, missing bolts, nuts. | | | |
| | Clips | Broken, missing. | | | |
| | Cotter Pins | Broken, missing. | | | |
| | | KICKSTAND | | | |
| ltem | Check | Look for | Notes | | |
| Centerstand | Condition | Cracks, bent. | | | |
| | Retention | Springs in place, tension to hold position. | | | |
| Sidestand | Condition | Cracks, bent (safety cut-out switch/pad if equipped). | | | |
| | Retention | Springs in place, tension to hold position. | | | |